




Propshafts

FRONT

1	FTC4140	PROPSHAFT	PETROL
1	FTC4140	PROPSHAFT	DIESEL MANUAL
1	TVB000130	PROPSHAFT	DIESEL AUTOMATIC
2	TVC100010	UNIVERSAL JOINT	
3	TVE100000	GAITER	
4	NY606041L	NUT	
5	509045P	BOLT	

REAR


1	FTC4141	PROPSHAFT	ALL	TO TA 321291
1	FTC4141	PROPSHAFT	PETROL	FROM TA 321292
1	FTC4141	PROPSHAFT	DIESEL	FROM TA 321292 MANUAL
1	FTC5066	PROPSHAFT	DIESEL	FROM TA 321292 AUTOMATIC
2	TVC100010	UNIVERSAL JOINT		
3	TVE100000	GAITER		
4	NY606041L	NUT		
5	509045P	BOLT		
6	TVF100010	PROPSHAFT COUPLING		
7	FTC5067	ADAPTOR		





Differential

B
E
A
R
M
A
C
H




1	TBB100830	DIFFERENTIAL ASSEMBLY - FRONT	
1	TBB100840	DIFFERENTIAL ASSEMBLY - REAR	2 PIN
1	TBB100900	DIFFERENTIAL ASSEMBLY - REAR	4 PIN
2	FTC4210	LOCKING RING	
3	STC2808	BEARING	
4	STC3124	FLANGE / MUDSHIELD / SEAL	
5	FTC3549	MUDSHIELD	
6	90513454	WASHER - MULTIPLE OPTIONS	
6	FTC5413	WASHER - MULTIPLE OPTIONS	
7	576159	ROLL PIN	

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only



Driveshaft



FRONT


1	TDB104080	DRIVESHAFT RH
1	TDB104090	DRIVESHAFT LH
2	STC3204	CV JOINT
3	STC3203	CV GAITOR
4	FTC4822	SEAL
5	FTC3226	HUB RH
5	FTC3243	HUB LH
6	FTC3548	SHIELD

REAR

7	TOD000000	DRIVESHAFT RH
7	TOD000010	DRIVESHAFT LH
8	FTC5209	SEAL
9	FTC2249	ADAPTOR - ABS
10	FTC1374	BUSH - ABS
11	FTC2999	BLANKING PLUG
12	FTC3223	HUB




Body




1	BKA720050	BONNET	
2	ETB100700	INSULATION	
3	MXC2258	HINGE	RH
3	MXC2259	HINGE	LH
4	ALR1164	FENDER	RH
4	ALR1165	FENDER	LH
5	ALR8994	FRONT WHEELARCH LINER	RH
5	ALR8995	FRONT WHEELARCH LINER	LH
6	ALR2646	REAR WHEELARCH LINER	RH
6	ALR2647	REAR WHEELARCH LINER	LH
7	DHB102620LML	GRILLE	
8	AWR2010LML	HEADLIGHT FINISHER	RH
8	AWR2011LML	HEADLIGHT FINISHER	LH
9	DAG100330	BADGE	GOLD
9	BTR8401	BADGE	SILVER

Body




1	ALR7416	A-POST REPAIR PANEL	RH
1	ALR7417	A-POST REPAIR PANEL	LH
2	ALR7418	B-POST REPAIR PANEL	RH
2	ALR7419	B-POST REPAIR PANEL	LH
3	ALR7420	REAR QUARTER REPAIR PANEL	RH
3	ALR7421	REAR QUARTER REPAIR PANEL	LH
4	ALR7422	CANTRAIL REPAIR PANEL	RH
4	ALR7423	CANTRAIL REPAIR PANEL	LH



1	ALR1196	FRONT BULKHEAD ASSEMBLY	
2	ALR1202	FRONT INNER WING	RH
2	ALR9465	FRONT INNER WING	LH
3	AMR2549	FUSE BOX MOUNTING BRACKET	



Doors




1	ASR1738	FRONT DOOR ASSEMBLY	RH	
1	ASR1739	FRONT DOOR ASSEMBLY	LH	
2	ALR24	FRONT DOOR SKIN	RH	
2	ALR25	FRONT DOOR SKIN	LH	
3	EJD101600	FRONT DOOR WATER SHEDDER	RH	
3	EJD101610	FRONT DOOR WATER SHEDDER	LH	
4	ALR8272	FRONT DOOR GLASS	RH	TO WA 410481
4	CUB102940	FRONT DOOR GLASS	RH	FROM XA 410482
4	ALR8271	FRONT DOOR GLASS	LH	TO WA 410481
4	CUB102950	FRONT DOOR GLASS	LH	FROM XA 410482
5	ALR8600	FRONT DOOR GLASS CHANNEL	RH	
5	ALR8601	FRONT DOOR GLASS CHANNEL	LH	
6	ALR8232	FRONT DOOR GLASS INNER SEAL	RH	
6	ALR8233	FRONT DOOR GLASS INNER SEAL	LH	
7	ALR3146	FRONT DOOR GLASS WASTERAIL	RH	
7	ALR3147	FRONT DOOR GLASS WASTERAIL	LH	
8	ALR6943	FRONT DOOR GLASS CHANNEL		

For Part Numbers 21-25 see next page.



Doors continued

9	ALR5964	REAR DOOR ASSEMBLY	RH	
9	ALR5965	REAR DOOR ASSEMBLY	LH	
10	ALR26	REAR DOOR SKIN	RH	
10	ALR27	REAR DOOR SKIN	LH	
11	ELD100920	REAR DOOR WATER SHEDDER	RH	
11	ELD100930	REAR DOOR WATER SHEDDER	LH	
12	CVB102120	REAR DOOR GLASS	RH	
12	CVB102130	REAR DOOR GLASS	LH	
13	ALR6358	REAR QTR GLASS	RH	TO WA 410481
13	CVB102160	REAR QTR GLASS	RH	FROM XA 410482
13	ALR6359	REAR QTR GLASS	LH	TO WA 410481
13	CVB102170	REAR QTR GLASS	LH	FROM XA 410482
14	ALR8602	REAR DOOR GLASS CHANNEL	RH	TO YA 442156
14	CGE101280	REAR DOOR GLASS CHANNEL	RH	FROM YA 442157
14	ALR8603	REAR DOOR GLASS CHANNEL	LH	TO YA 442156
14	CGE101290	REAR DOOR GLASS CHANNEL	LH	FROM YA 442157
15	ALR6940	REAR QTR SEAL	RH	
15	ALR6941	REAR QTR SEAL	LH	
16	ALR6880	REAR DOOR GLASS CHANNEL	RH	
16	ALR6881	REAR DOOR GLASS CHANNEL	LH	
17	ALR5948	REAR DOOR GLASS CHANNEL	RH	
17	ALR5949	REAR DOOR GLASS CHANNEL	LH	
18	ASR2432	REAR DOOR GLASS WASTERAIL	RH	TO XA 422229
18	DDE101540	REAR DOOR GLASS WASTERAIL	RH	FROM XA 422230
18	ASR2433	REAR DOOR GLASS WASTERAIL	LH	TO XA 422229
18	DDE101550	REAR DOOR GLASS WASTERAIL	LH	FROM XA 422230
19	ALR7952	SEAL - REAR WHEELARCH	RH	
19	ALR7953	SEAL - REAR WHEELARCH	LH	
20	ALR6944	REAR DOOR CHANNEL		
21	ALR3382	UPPER DOOR HINGE	RH	
21	ALR3383	UPPER DOOR HINGE	LH	
22	ALR3384	LOWER DOOR HINGE	RH	
22	ALR3385	LOWER DOOR HINGE	LH	
23	BDH130011L	CHECKER ASSEMBLY		
24	ALR3733	MOUNTING BRACKET		
25	BDM10001L	PIN - CHECK ARM		TO VA 359387
25	BDM100050	PIN - CHECK ARM		FROM VA 359388




Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only




Bumpers




1	ANR2332	FRONT BUMPER	LESS SPOILER	TO XA 430701
1	DPB103830	FRONT BUMPER	WITH SPOILER	TO XA 430701
1	DPB104600LYT	FRONT BUMPER		FROM XA 430702
2	ANR3686	SEAL - FRONT BUMPER		
3	NTC9714	SPOILER	RH	
3	NTC9713	SPOILER	LH	
4	ANR1996	FOG LAMP BLANKING PLATE	RH	
4	ANR1997	FOG LAMP BLANKING PLATE	LH	
5	ANR4150	DUCT - COLD AIR INTAKE	DIESEL	AUTOMATIC
6	ANR2276	RUBBER FRONT BUFFER		
7	ANR4456	CAN - CRUSH		
8	ANR3617	PLATE - CRUSH CAN		
9	ANR3616	WASHER - CRUSH CAN		
10	ANR4114	BRACKET - FRONT BUMPER MOUNTING	RH	
10	ANR4115	BRACKET - FRONT BUMPER MOUNTING	LH	
11	ANR2500	BRACKET		
13	ESR3433	BAFFLE - AIR DUCT		
14	ANR2535	REAR BUMPER		TO TA 346793
14	ANR4735	REAR BUMPER		FROM VA 346794
14	STC7161P	REAR BUMPER		TO TA 346793 AUTOBIOGRAPHY
14	STC4031P	REAR BUMPER		FROM VA 346794 AUTOBIOGRAPHY
15	NTC8402	CLIP - REAR BUMPER		
16	ANR3687	SEAL - REAR BUMPER		
17	NTC7882	PANEL - REAR BUMPER	RH	
17	NTC7881	PANEL - REAR BUMPER	LH	
18	ANR3045	EXTENSION - WHEELARCH LINER	RH	
18	ANR4974	EXTENSION - WHEELARCH LINER	LH	
19	ANR2381	BRACKET - REAR BUMPER		



Regulators / Seals / Mirrors




- 1 CVF100740 FRONT REGULATOR RH
- 1 CVF100750 FRONT REGULATOR LH
- 2 ASR2498 MOTOR RH
- 2 ASR2499 MOTOR LH
- 3 ASR2496 REAR REGULATOR RH
- 3 ASR2497 REAR REGULATOR LH



- A BHK720020 TAILGATE APERTURE SEAL


- 1 ALR6283LNF FRONT DOOR SEAL
- 2 ALR6285LNF REAR DOOR SEAL
- 3 ALR6938 A-POST SEAL RH
- 3 ALR6939 A-POST SEAL LH
- 4 ALR6316 B/C POST SEAL RH
- 4 ALR6317 B/C POST SEAL LH



- A STC4625 ADAPTOR
- B BTR6072 MIRROR GLASS RH TO XA 430701
- B BTR6073 MIRROR GLASS LH TO XA 430701
- B CRD000310 MIRROR GLASS RH YA 430702 ON
- B CRD000330 MIRROR GLASS LH YA 430702 ON
- B CRD101240 MIRROR GLASS RH * YA 430702 ON
- B CRD101250 MIRROR GLASS LH * YA 430702 ON


* ELECTROCHROMATIC

MULTIPLE OPTIONS ON MIRROR ASSEMBLIES, SEE FICHE





Braking Systems



FRONT

1	NTC8780	DISC BRAKE	
2	SFP100480	SET PADS	
3	STC1916	CALIPER RH	
3	STC1915	CALIPER LH	
4	STC1918	PISTON	
5	STC1919	SEAL KIT	
6	STC1920	GUIDE PIN KIT	
7	STC1917	CALIPER CARRIER	
8	FTC3544	DISC COVER RH	TO VA 376579
8	FTC3545	DISC COVER LH	FROM WA 376580
8	FTC4908	DISC COVER RH	TO VA 376579
8	FTC4909	DISC COVER LH	FROM WA 376580


REAR

1	SDB000470	DISC BRAKE	
2	SFP100490	SET PADS	
3	STC1906	CALIPER RH	
3	STC1905	CALIPER LH	
4	STC1908	PISTON	
5	STC1909	SEAL KIT	
6	STC1910	GUIDE PIN KIT	
7	STC1907	CALIPER CARRIER	
8	FTC3546	DISC COVER RH	



Handbrake

B
E
A
R
M
A
C
H




- | | | | |
|---|-----------|--------------------------------|----------------|
| 1 | NTC9859 | DRUM - TRANSMISSION BRAKE | |
| 2 | ICW100030 | SET SHOES - TRANSMISSION BRAKE | |
| 3 | STC1535 | BACKPLATE | TO XA 425461 |
| 3 | ICL100010 | BACKPLATE | FROM XA 425462 |
| 4 | ICW100050 | RETENTION KIT | |
| 5 | ANR2215 | CABLE | |
| 6 | SF108201L | SCREW | |

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only




Clutch




0	FTC5200	RELEASE BEARING	PETROL		
0	STC2079L	RELEASE BEARING	DIESEL		
1	FTC1008	CLUTCH PLATE	PETROL	TO (E) 42D 27823A	(USE FTC5426)
1	FTC4488	CLUTCH PLATE	DIESEL		
2	FTC1009	CLUTCH COVER	PETROL	TO (E) 42D 27823A	(USE FTC5426)
2	FTC2157	CLUTCH COVER	DIESEL		
1+2	FTC5426	CLUTCH PLATE & COVER	PETROL	FROM (E) 42D 27824A	
3	ANR3894	MASTER CYLINDER			
4	ANR2967	SLAVE CYLINDER			
5	FTC2170	PUSH ROD			
6	FTC2174	BOOT - CLUTCH RELEASE			
7	FTC2189	RELEASE LEVER INSERT			
8	FTC2166	SHAFT/LEVER ASSEMBLY	PETROL		
8	FTC4085	SHAFT/LEVER ASSEMBLY	DIESEL		
9	FTC1667	CLUTCH RELEASE ARM			
10	FTC2169	BUSH			
11	FTC1010	BUSH			



Cooling



Viscous Unit, Fan. Water Pump & Thermostat



DIESEL

1	PCC108460	RADIATOR	MANUAL
1	PCC108470	RADIATOR	AUTOMATIC
2	ESR2544	FAN COWL	
3	PCH124720	BOTTOM HOSE	
4	PCH116950	TOP HOSE	EXCEPT EGR
4	PCH124730	TOP HOSE	EGR
5	EJP1483L	BUSH	


PETROL

A	PCC106940	RADIATOR	TO WA 410481
A	PCC106850	RADIATOR	FROM XA 410482
B	ESR3292	LOWER FAN COWL	
C	ESR3291	UPPER FAN COWL	TO WA 410481
C	PGK100690	UPPER FAN COWL	FROM XA 410482
D	PCH118820	HOSE - RAD TO THERMOSTAT	
E	PEM101130	THERMOSTAT HOUSING	
F	PEH101520	HOSE - BYPASS TO THERMOSTAT	
G	PEH101520	HOSE - HEATER TO THERMOSTAT	TO WA 410481
G	PCH118810	HOSE - HEATER TO THERMOSTAT	FROM XA 410482
H	PEH101590	HOSE - THERMOSTAT TO WATER PUMP	
J	PCH114840	TOP HOSE	TO WA 410481
J	PCH000900	TOP HOSE	FROM XA 410482
K	ERR4685	O-RING	
L	ERR4686	PLUG	
M	EJP1483L	BUSH	

ERR4996	VISCOUS UNIT - PETROL	
ERR4960	FAN UNIT - PETROL	
PGG101290	FAN & VISCOUS UNIT - DIESEL	
STC4378	WATER PUMP - PETROL	
STC2192	WATER PUMP - DIESEL	TO MA 303747
STC3342	WATER PUMP - DIESEL	FROM MA 303748
PEM101130	THERMOSTAT - PETROL	
STC3338	THERMOSTAT - DIESEL	




Cooling & Heating Heaters



1	STC3266	MOTOR - BLEND HEATER
2	STC3259	MOTOR - FLAP CONTROL
3	STC3366	GROMMET
4	STC3261	HEATER MATRIX
5	STC3262	O-RING
6	STC3264	PIPE - OUTLET TO HEATER
7	STC3263	PIPE - COOLANT TO HEATER
8	JQD100340	EXPANSION EVAPORATOR VALVE
9	STC3260	EVAPORATOR - A/CON
10	JYX100150L	O-RING - LARGE/SUCTION
11	JYX100160L	O-RING - SMALL/LIQUID

Cooling & Heating Intercooler





1	ESR2504	INTERCOOLER	
2	ESR3289	HOSE	EXCEPT EGR
2	ESR4122	HOSE	EGR
3	ESR3290	HOSE	TO VA 376579
3	PNH101710	HOSE	FROM WA 376580
4	ESR1483	HOSE	
5	ESR3295	HOSE	
6	PYC101120L	CLIP	



**B
E
A
R
M
A
C
H**

Sensors




1	STC2786	ABS	FRONT		
2	STC2787	ABS	REAR	2 PIN DIFF	TO (A) 50S 02483A
2	STC2787	ABS	REAR	4 PIN DIFF	TO (A) 51S 03121A
2	STC2922	ABS RH	REAR	2 PIN DIFF	(A) 50S 02483A - TA 346793
2	STC2921	ABS LH	REAR	2 PIN DIFF	(A) 50S 02483A - TA 346793
2	STC2922	ABS RH	REAR	4 PIN DIFF	(A) 51S 03121A - TA 346793
2	STC2921	ABS LH	REAR	4 PIN DIFF	(A) 51S 03121A - TA 346793
2	STC3385	ABS	REAR		FROM VA 346794
3	YWC103640LUM	ULTRASONIC	MINK GREY		
4	STC2299	ECU COOLANT TEMPERATURE	DIESEL		
4	STC2302	AIR TEMPERATURE	DIESEL		
5	ERR3561	TURBO BOOST PRESSURE	DIESEL		
6	AMR3270	WINDSCREEN WASH LEVEL			
7	STC3257	AMBIENT AUTO A/CON			TO WA 381430
7	JTF100270	AMBIENT AUTO A/CON			FROM WA 381431

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only




Sensors



8	ERR1834	LAMBDA	PETROL	TO VA 350483
8	AMR6244	LAMBDA	PETROL	VA 350484 - WA 410481
8	MHK100940	LAMBDA	PETROL	FROM XA 410482
9	ERR5211	CATALYST TEMPERATURE	PETROL	
10	BTR9733	SOLAR AUTO A/CON		
11	JTF000030	IN CAR TEMPERATURE		
12	ERR5212	ECU - CATALYST		
13	ETC8496	TEMPERATURE	PETROL	TO WA 410481
13	MEK100160	TEMPERATURE	PETROL	FROM XA 410482
14	ERR4278	POTENTIOMETER	PETROL	
15	STC3258	TEMPERATURE - EVAPORATOR		TO MA 300000 approx
15	STC3365	TEMPERATURE - EVAPORATOR		FROM MA 3000001 approx
16	STC3256	TEMPERATURE - HEATER		
17	WQT100030L	INERTIA FUEL PUMP		
18	AS 8	LAMBDA	PETROL	
19	ERR5595	AIRFLOW - MPI	PETROL	TO WA 410481
19	MHK100800	AIRFLOW - MPI	PETROL	FROM XA 410482
20	ERR2261	CAMSHAFT - ENGINE	PETROL	TO TA 346793
20	ERR6169	CAMSHAFT - ENGINE	PETROL	FROM VA 346794
21	ERR5594	KNOCK IGNITION	PETROL	TO WA 410481
21	NSC100650	KNOCK IGNITION	PETROL	FROM XA 410482
22	ERR4352	MOTOR - STEPPER - MPI	PETROL	



Switches



TO WA 410481


1	AMR3964	LIGHTS - ROTARY	
2	AMR3712	REAR FOG - PUSH PUSH	
3	AMR3711	FRONT FOG - PUSH PUSH	
4	AMR4141	CRUISE CONTROL	
5	AMR3708	TRANSFER BOX - HIGH / LOW	
6	AMR5823	RIDE HEIGHT CONTROL	
7	AMR3709	RIDE HEIGHT DISABLE	
8	AMR2691	HAZARD LIGHT	
9	AMR2754	SWITCH BLANK	
10	AMR3388	FUEL FLAP RELEASE	
11	AWR1083	CENTRE CONSOLE SWITCH PACK	SUNROOF
11	AWR1084	CENTRE CONSOLE SWITCH PACK	EXCEPT SUNROOF
11	YUB000040AYZ	CENTRE CONSOLE SWITCH PACK	30th ANNIVERSARY
12	AMR3762	ELECTRIC WINDOW LIFT	

FROM XA 410481

1	YUK100240	LIGHTS - ROTARY	
2	YUG102260	REAR FOG - PUSH PUSH	
3	YUG102250	FRONT FOG - PUSH PUSH	
4	YUH100340	CRUISE CONTROL	
5	YUG102240	TRANSFER BOX - HIGH / LOW	
6	YUF101930	RIDE HEIGHT CONTROL	
7	YUG102270	RIDE HEIGHT DISABLE	
8	YUG102480	HAZARD LIGHT	
9	YXJ100170	SWITCH BLANK	
10	YUG102490	FUEL FLAP RELEASE	
11	YUB100900	CENTRE CONSOLE SWITCH PACK	EXCEPT SUNROOF
11	YUB100920	CENTRE CONSOLE SWITCH PACK	SUNROOF
11	YUB101100	CENTRE CONSOLE SWITCH PACK	BURR WALNUT
12	YUF101570	ELECTRIC WINDOW LIFT	



Lighting



LH DRIVE PARTS		
1	XBC105960	HEADLAMP RH
1	XBC105970	HEADLAMP LH

LH DRIVE PARTS		
1	XBC105720	HEADLAMP RH
1	XBC105730	HEADLAMP LH

TO XA 430701 (ORANGE INDICATORS)

1	XBC105940	HEADLAMP RH
1	XBC105950	HEADLAMP LH
2	AMR2690	INDICATOR RH
2	AMR2688	INDICATOR LH
3	PRC9916	SIDE REPEATER
4	AMR4100	REAR LAMP RH - BODY
4	AMR4099	REAR LAMP LH - BODY
5	AMR4724	REAR LAMP RH - TAILGATE
5	AMR4725	REAR LAMP LH - TAILGATE
6	STC2994	SIDE LIGHT BULB HOLDER
7	XBP100180	INDICATOR BULB HOLDER
8	AMR2481	DOOR LAMP
9	AMR3020	NUMBER PLATE LAMP
10	PRC7644	HIGH LEVEL BRAKE LIGHT




FROM YA 430702 (CLEAR INDICATORS)

1	XBC105700	HEADLAMP RH
1	XBC105710	HEADLAMP LH
2	XBD100920	INDICATOR RH
2	XBD100930	INDICATOR LH
3	XGB000020	SIDE REPEATER
4	XFB101720	REAR LAMP RH - BODY
4	XFB101730	REAR LAMP LH - BODY
5	XFE100220	REAR LAMP RH - TAILGATE
5	XFE100230	REAR LAMP LH - TAILGATE
6	STC2994	SIDE LIGHT BULB HOLDER
7	XBP100200	INDICATOR BULB HOLDER
8	AMR2481	DOOR LAMP
9	AMR3020	NUMBER PLATE LAMP
10	PRC7644	HIGH LEVEL BRAKE LIGHT



Miscellaneous Engine Parts

B
E
A
R
M
A
C
H



2.5 BMW DIESEL

ALTERNATOR	STC2227	105 AMP
STARTER MOTOR	ERR5445	
GASKET - EXHAUST MANIFOLD - DOWNPIPE	STC3697	
GASKET - HEAD	STC2031	
GASKET - INLET MANIFOLD	STC2203	
GASKET - ROCKER COVER	STC2026	TO (E) 34928373
GASKET - ROCKER COVER	STC4177	FROM (E) 34928374
GASKET - SUMP	STC2036	
GASKET - TIMING COVER	STC2045	
GASKET - TURBO OIL DRAIN PIPE	LHV100240L	
GASKET - TURBO TO EXHAUST MANIFOLD	STC2209	
GASKET KIT - BLOCK	STC2012	
GASKET KIT - HEAD	STC3694	
OIL SEAL - CRANKSHAFT (FRONT COVER)	STC4397	
OIL SEAL - CRANKSHAFT REAR MAIN	LUF100540L	
OIL SEAL - VALVE STEM SET	STC2159	
TAPPET	STC2144	

4.0 / 4.6 V8 PETROL

ALTERNATOR	AMR4247	100 AMP
ALTERNATOR	AMR2937	120 AMP
ALTERNATOR	ERR5834	150 AMP
STARTER MOTOR	NAD101490	
BEARING - CRANKSHAFT SET	STC4299	
GASKET - EXHAUST MANIFOLD	ERR6733	
GASKET - HEAD	ERR7217	
GASKET - INLET MANIFOLD	ERR7306	
GASKET - ROCKER COVER	LVC100260	
GASKET - SUMP	LVF100400	
GASKET - THROTTLE BODY	ERR6623	
GASKET - TIMING COVER	ERR7280	
GASKET - WATER PUMP	ERR4077	
OIL SEAL - CRANKSHAFT (FRONT COVER)	ERR6490	
OIL SEAL - CRANKSHAFT REAR MAIN	ERR2640	
OIL SEAL - VALVE STEM	ERR1782	
PULLEY - CRANKSHAFT	LHG000060	
SEAL - INLET MANIFOLD GASKET	ERR7283	
TAPPET	ERC4949	

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only


QUICK REFERENCE

PAGE
18

PARTS SUITABLE FOR
RANGE ROVER - P38



Exhaust Manifold




1	LKC100470	EXHAUST MANIFOLD RH	PETROL
1	LKC100480	EXHAUST MANIFOLD LH	PETROL
2	ERR6733	EXHAUST MANIFOLD GASKET	PETROL
3	STC2207	EXHAUST MANIFOLD	DIESEL TO (E) 31428932
3	STC4209	EXHAUST MANIFOLD	DIESEL FROM (E) 31438932
4	STC3697	EXHAUST MANIFOLD GASKET	DIESEL




B
E
A
R
M
A
C
H

Exhaust Diesel



1	ESR2521	DOWNPIPE	MANUAL
1	ESR3975	DOWNPIPE	AUTOMATIC
2	ESR3194	CENTRE SILENCER	
3	ESR3196	REAR SILENCER	SINGLE TAILPIPE TO VA 346794
3	WDV100270	REAR SILENCER RH	TWIN TAILPIPE FROM VA 346795
3	WDV100260	REAR SILENCER LH	TWIN TAILPIPE FROM VA 346795
4	ESR1069	OLIVE	
5	NV108041L	NUT	

Exhaust Petrol



1	ESR4095	DOWNPIPE	TO WA 410481
1	WCD105350	DOWNPIPE	FROM XA 410482
2	ESR3195	CENTRE SILENCER	TO VA 376579
2	WCE104310	CENTRE SILENCER	FROM WA 376580
3	ESR3538	REAR SILENCER	SINGLE TAILPIPE TO VA 346793
3	ESR4126	REAR SILENCER	SINGLE TAILPIPE VA 346794 - WA 410481
3	WDV100250	REAR SILENCER	SINGLE TAILPIPE FROM XA 410482
3	WDV100270	REAR SILENCER RH	TWIN TAILPIPE FROM VA 346795
3	WDV100260	REAR SILENCER LH	TWIN TAILPIPE FROM VA 346795
4	ESR3153	FINISHER	
5	ESR3260	GASKET	
6	FX110047L	NUT	
7	NV108041L	NUT	
8	WYB10005	BLANKING PLUG	TO WA 410481
8	MYB100040L	BLANKING PLUG	FROM XA 410482

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only




Fuel Tank

PETROL

1	WFE107480	FUEL TANK	TO WA 410481
1	WFE107030	FUEL TANK	FROM XA 410482
2	ESR3190	CRADLE	
3	NTC5859	SEAL	TO WA 410481
3	ESR3806	SEAL	FROM XA 410482
4	STC4344	FUEL PUMP	TO WA 410481
4	WFX101400	FUEL PUMP	FROM XA 410482
5	NTC5858	LOCKING RING	TO WA 410481
5	ESR3808	LOCKING RING	FROM XA 410482

DIESEL


1	WFE107040	FUEL TANK	
2	ESR3190	CRADLE	
3	NTC5859	SEAL	
4	ESR1111	FUEL SENSOR	
5	NTC6872	LOCKING RING	





Service Items

B
E
A
R
M
A
C
H



4.0 + 4.6 V8 EFI

OIL FILTER	ERR3340	
AIR FILTER	ESR341	TO TA 346793 (1)
AIR FILTER	ESR4238	FROM VA 346794 (1)
FUEL FILTER	ESR4065	
SPARK PLUG	ERR3799	
CRANK VENT	ERR4563	
ROCKER GASKET	ERR7288	
SUMP GASKET	LVF100400	
SUMP WASHER	UAM2857L	

2.5 BMW DIESEL

OIL FILTER (to NOV 95)	STC2180	TO NOV 95
OIL FILTER(from DEC 95)	STC3350	FROM DEC 95
AIR FILTER(toTA346793)	ESR341	TO TA 346793
AIR FILTER(fromVA346794)	ESR4238	FROM VA 346794
FUEL FILTER	STC2827	
ROCKER GASKET	STC2026	TO ENG 34928373
ROCKER GASKET	STC4177	FROM ENG 34928374
SUMP GASKET	STC2036	
SUMP WASHER	STC3101	

ENGINE BELTS

PETROL - NO A/CON	ERR4461	FAN/PAS/ALTERN BELT
PETROL - A/CON	ERR4460	FAN/PAS/ALTERN/ACON BELT
PETROL	ERR6439	DRIVE BELT TENSIONER
PETROL	ERC7929	TIMING BELT
PETROL	ERR4421	FRONT COVER GASKET
PETROL	ERR4077	W/PUMP GASKET
DIESEL	STC2134	FAN/PAS/ALTERN BELT
DIESEL	STC2128	DRIVE BELT TENSIONER-SMALL
DIESEL	STC2132	DRIVE BELT TENSIONER -BIG
DIESEL	STC3397	AIR CON BELT
DIESEL	STC2142	TIMING BELT
DIESEL	STC2045	FRONT COVER GASKET
DIESEL	STC2189	W/PUMP GASKET

Tel: +44 (0)29 20 856 550

Manufacturers' part numbers are used for reference purposes only


QUICK REFERENCE

PAGE
22

PARTS SUITABLE FOR
RANGE ROVER - P38



Steering



1	STC1968	STEERING JOINT		
2	ANR6398	STEERING SHAFT		
3	ANR5320	STEERING BOX	RHD	
4	STC3575	SEAL		
5	STC3574	CIRCLIP		
6	ANR4382	DROP ARM		
7	ANR1184	WASHER		
8	ANR1341	NUT		
9	QEP105990	PIPE - BOX TO RESEVOIR		FROM XA410482
10	ANR2367	PIPE - RESEVOIR TO PUMP - SUCTION		TO WA 410481
10	QEH102230	PIPE - RESEVOIR TO PUMP - SUCTION		FROM XA 410482
10	ANR6583	PIPE - RESEVOIR TO PUMP - SUCTION		
11	ANR3855	PIPE - PUMP TO BOX	RHD	TO VA 375483
11	QEP104660	PIPE - PUMP TO BOX	RHD	VA 375484 - WA 410481
11	QEP105440	PIPE - PUMP TO BOX	RHD	FROM XA 410482
11	ANR4330	PIPE - PUMP TO BOX	RHD	TO VA 375483
11	QEP104670	PIPE - PUMP TO BOX	RHD	FROM VA 375484
12	QHG000060	DRAG LINK ASSEMBLY	RHD	
13	TIQ000020	TRACK ROD ASSEMBLY		
14	QEK000040	DRAG LINK TUBE		
15	STC3107	CLAMP		LARGE
16	STC3108	CLAMP		SMALL
17	STC3109	NUT - FLANGE		
18	ANR1000	NUT		
19	QFS000010	BALL JOINT		SHORT ARM
20	QFS000060	BALL JOINT		LONG ARM
21	ANR2640	STEERING DAMPER		
22	STC1943	BUSH		
23	QVB101090	POWER STEERING PUMP		TO WA 410481
23	QVB000040	POWER STEERING PUMP		XA 410482 - YA 444661
23	QVB000050	POWER STEERING PUMP		FROM YA 444662
23	ERR4911	POWER STEERING PUMP		DIESEL


LH DRIVE PARTS

11	ANR3856	PIPE - PUMP TO BOX	LHD	TO WA 410481
11	QEP104910	PIPE - PUMP TO BOX	LHD	FROM XA 410482
12	QHG000070	DRAG LINK ASSEMBLY	LHD	
12	ANR5321	STEERING BOX	LHD	



B
E
A
R
M
A
C
H

Air Suspension



FRONT

1	STC3672	DAMPER - FRONT	
2	ANR3720	WASHER	
3	RNF100090L	BUSH	
4	NV210047	NUT	
5	REB101740	SPRING - FRONT	
6	ANR2556	BUMP STOP	
7	STC3579AA	FRONT SENSOR RH	TO TA 346793
7	STC3578AA	FRONT SENSOR LH	TO TA 346793
8	STC2763	LINK - FRONT SENSOR	
9	ANR4686	FRONT SENSOR	FROM VA 346794
10	NTC9127	PIN	
11	NTC9449	CLIP	

REAR

12	STC3671	DAMPER - REAR	
13	RNF100090L	BUSH	
14	ANR3720	WASHER	
15	NV210047	NUT	
16	RKB101460	SPRING - REAR	
17	STC3593AA	REAR SENSOR RH	TO TA 346793
17	STC3594AA	REAR SENSOR LH	TO TA 346793
18	ANR4687	REAR SENSOR	FROM VA 346794
19	STC2765	LINK - REAR SENSOR	
20	ANR2556	BUMP STOP	
21	ANR1148	CLIP	


QUICK REFERENCE

PAGE
24

PARTS SUITABLE FOR
RANGE ROVER - P38



Suspension



LH DRIVE PARTS

ANR3665 Panhard Rod Front

1	ANR3666	PANHARD ROD - FRONT
1	ANR3670	PANHARD ROD - REAR
2	ANR3671	BUSH
3	ANR4386	BOLT
4	ANR3140	NUT
5	ANR3793	ANTI ROLL BAR

6	ANR3304	ANTI ROLL BAR LINK
7	ANR3305	BUSH
8	ANR2575	CLAMP
9	ANR2638	BOLT
10	ANR1000	NUT
11	ANR3543	RADIUS ARM - REAR

12	ANR6920	BOLT
13	ANR3285	BUSH
14	ANR3330	RADIUS ARM - FRONT - RH
14	ANR3331	RADIUS ARM - FRONT - LH
15	ANR2570	BOLT - M16
15	RYG101340	BOLT - M16x110mm

16	ANR3313	BOLT
17	ANR1191	BOLT
18	ANR3332	BUSH
19	ANR2635	WASHER
20	ANR2563	BUSH
21	NTC9285	WASHER